

# INSTALLATION INSTRUCTIONS

## For Large Manholes such as the 68, 78, 78DA, 78TA, 88 and 98 series

After Storage tank has been installed and final grade level has been determined, observe the following instructions:

- The bottom of the run off should be flush with or anywhere up to 1" above grade level.
- As per local construction codes and guidelines, pour pea gravel and concrete in around manhole and let set. Assure concrete is poured such that, the concrete stiffening flange (if available) is embedded in the mixture to strengthen the manhole.

**NOTE:** Make sure you are accurate when measuring runoff height, because it is crucial to proper surface water drainage.

### **ALWAYS TEST CONTAINMENT MANHOLE FOR LEAKS (78DA and 78TA)**

*After the concrete has been poured, re-test the unit to make sure no damage occurred during the installation.*

*This unit should be tested and inspected every 6 months, or more frequently if you are a high volume user or if conditions warrant. Damaged or leaking units should be replaced immediately.*

*Rain Tight versions such as the 78 and 98 should have the seals checked as well.*



Universal Valve Co., Inc.  
478 Schiller St.  
Elizabeth, NJ 07206  
(908) 351-0606  
Fax: (908) 351-0369